


**Model DVSD-3000 MTS/LR
STORECASTER & MESSAGE-ON-HOLD
SYSTEM WITH LOCAL RECORD**

- 1 MESSAGE SELECTION 1-20:**
Enable and disable messages to be played or recorded. Off (down) On (up).
- 2 APPEND MODE LED (YELLOW):**
Indicates if system is in Standard mode (OFF) or Replace & Append mode (ON).
- 3 MEMORY OK LED (GREEN):**
LED is ON if either an SD Card or a USB memory key with valid audio messages is detected by the system. Blinks if no files are detected.
- 4 LOCAL RECORD PUSHBUTTON:**
Press this button to initiate local record function.
- 5 APPEND PUSHBUTTON:**
Toggles the Append mode as displayed on the associated LED.
- 6 RECORD STOP PUSHBUTTON:**
Stop playing downloaded messages. If pressed during the recording process the recording will be stopped.
- 7 BGM LEVELS KNOB:**
Adjusts level of external music source.
- 8 FADE AMOUNT KNOB:**
Adjusts amount the BGM input is ducked when a message is played.
- 9 TONE ADJUST KNOB:**
Adjusts the Bass & Treble amount to deliver the best overall system performance.
- 10 POWER JACK:**
Insert supplied power adapter.



- 11 BGM INPUT:**
Connect to external source of music.
- 12 LINE OUTPUT:**
Audio output level of up to +3dB into 600 Ω, this is a standard level for most applications.
- 13 SPEAKER OUTPUT:**
Audio output level of up to 2.5W into 8 Ohm. Use this output if more drive is needed to reach a more comfortable listening level.
- 14 LOCAL RECORD INPUT:**
use with LR-HSET (Optional) Hand set for local recording.
- 15 AUDIO OUTPUT LEVEL KNOB:**
Adjusts the volume to both the line level and speaker audio outputs.
- 16 SPEAKER PUSHBUTTON:**
Turns local Monitor speaker ON/OFF.
- 17 COPYING LED (RED):**
Used to display recording mode. Red light ON, indicates message (s) is being copied from USB memory key to SD Card.

COPYRIGHT POLICY

Recording, downloading or playing of copyrighted material such as sound effects, narration or music is unlawful unless permitted by a legal exception or consented to by the rights owner. Recording and download equipment should only be used with material that you have the legal right to copy and you are responsible for obtaining these rights, Mackenzie Laboratories, Inc. has no right to grant such permission.

- 18 PLAYING LED (GREEN):**
This green LED is ON when the system is playing Pre-Recorded messages.
- 19 PLAY MODE SWITCH:**
UP = music only. (Only BGM heard)
MID = music & message. (Normal operation)
DOWN = message only. (BGM muted)
- 20 MUSIC INTERVAL-Tens and Ones Rotary Switches:**
Set music interval between message plays. Set the rotary switches to the desired time between 00 and 99.
- 21 MUSIC INTERVAL-Minute/Second Switch:**
Programs rotary switch setting for minutes or seconds.
- 22 USB MEMORY KEY CONNECTOR:**
Audio files can be played directly from a USB memory key, or the files on it can be copied to an SD card, if one is present.
- 23 SD CARD CONNECTOR:**
Audio files be played directly from an SD card
- 24 MONITOR SPEAKER:**
Allows user to preview message play back.

**THE MACKENZIE DYNAVOX
DVSD-3000 MTS/LR Quikey**

15 JAN 2009, Version 1.1
Mackenzie Laboratories, Inc.
1163 Nicole CT, Glendora, CA 91740 USA
TEL (909) 394-9007 FAX (909)394-9411
www.macklabs.com